

// TECHNICAL
CATALOGUE

E75FD
E75FPD

FLAT DOOR SYSTEMS
WITH THERMAL BREAK



E75FD
E75FPD
FLAT DOOR SYSTEMS WITH THERMAL BREAK

TABLE OF CONTENTS

BUILDING PHYSICS

page 9

I.

E75FD FLAT DOOR SYSTEM WITH THERMAL BREAK

GENERAL INFORMATION

page 23

TABLES

page 27

PROFILES

page 33

SECTIONS

page 43

GLAZING OPTIONS

page 67

CUTTING LISTS & MACHINING

page 71

ACCESSORIES

page 137

II.

E75FPD FLAT DOOR SYSTEM WITH THERMAL BREAK

GENERAL INFORMATION

page 161

TABLES

page 165

PROFILES

page 171

SECTIONS

page 179

CUTTING LISTS & MACHINING

page 197

ACCESSORIES

page 225

III.

CE MARKING

page 241

ETEM HISTORY

ETEM is a leading aluminium extrusion company. It was founded in 1971 as a part of the largest metal manufacturing holding on the Balkans. With over 50 years of experience ETEM is a fully integrated designer and producer of architectural systems and aluminium profiles for industrial applications.

Our mission is to listen and promptly respond to our customers' requests and design and manufacture aluminium products and systems, taking into consideration technical and aesthetic requirements.

ETEM focuses on sustainable development and has proven its concern about the protection of the natural environment by making considerable investments in anti-pollution measures and by optimizing production processes following the applicable standards of the European Union.

SERVICES WE PROVIDE

ETEM supports you with the following:

- ▷ design of conventional and bespoke architectural system solutions
- ▷ innovative engineering in the field of curtain walls, ventilated facades, doors, windows
- ▷ professional consultation and adequate technical advices ensured by our engineering team with wide experience in the field of profile extrusion as well as architectural systems' engineering
- ▷ reliable customer care constant support trainings, technical support and audits on site
- ▷ high quality engineering which guarantees offering the best solution according to the specific features of every single project
- ▷ managing the process of certification in accordance with the applicable European standards in Notified Bodies
- ▷ production of non-standard length profiles and non-standard processing
- ▷ high quality powder coating

ETEM PRODUCTS AND SUSTAINABLE DEVELOPMENT

SUSTAINABLE DEVELOPMENT IS DEVELOPMENT THAT MEETS THE NEEDS OF THE PRESENT WITHOUT COMPROMISING THE ABILITY OF FUTURE GENERATIONS TO MEET THEIR OWN NEEDS.*

For many, sustainable development is about environmental conservation. This is true but it also includes two other aspects: a social aspect and an economic aspect.

Sustainable development means striking the right balance between economic development, social equity and environmental protection.


For us meeting this objective translates into the challenge of satisfying market demands at the lowest economic, social and environmental cost possible.

ETEM has always designed architectural systems which are in compliance with all requirements for achieving high energy efficiency.

In order to assure the comfort of the building inhabitants, ETEM systems adapt their functions to the changing environment.

As a moderator between outside and inside our systems provide:

- › ENERGY EFFICIENCY
- › DAYLIGHT
- › SUN-SHADING
- › VENTILATION AND GOOD AIR QUALITY
- › SAFETY AND SECURITY



* Extract from Brundtland Report, from the United Nations World Commission on Environment and Development WCED

BUILDING PHYSICS

DIMENSIONING / FORMULAS / EXAMPLES

ALUMINIUM AS MATERIAL

ALUMINIUM IS A VERY YOUNG METAL, EXTRACTED FOR THE FIRST TIME IN 1854. COMMERCIALLY PRODUCED AS A PRECIOUS METAL FROM 1886, ITS INDUSTRIAL PRODUCTION FOR CIVIL APPLICATIONS ONLY ACHIEVED WIDE USE IN THE 1950'S.

NOW ALUMINIUM PLAYS A KEY ROLE FOR THE SUSTAINABILITY OF NEW BUILDINGS AND THE RENOVATION OF EXISTING ONES. THANKS TO ITS PERFORMANCE PROPERTIES ALUMINIUM CONTRIBUTES TO THE ENERGY PERFORMANCE, SAFETY AND COMFORT OF NEW BUILDINGS.

ADVANTAGES

DESIGN FLEXIBILITY

The extrusion process offers an almost infinite range of forms and sections, allowing designers to integrate numerous functions into one profile

LONG SERVICE LIFE

Aluminium building products are made from alloys that are weatherproof, corrosion-resistant and immune to the harmful effects of UV rays, ensuring optimal performance over a very long period of time

HIGH STRENGTH-TO-WEIGHT RATIO

Thanks to the metal's inherent strength and stiffness, aluminium window and curtain wall frames can be very narrow. Material's light weight makes it easier to transport and handle on-site, reducing the risk of work-related injury

HIGH-REFLECTIVITY

This characteristic feature makes aluminium a very efficient material for light management. Aluminium shading devices can be used to reduce the need for air conditioning in summer

FIRE SAFETY

Aluminium does not burn and therefore is classified as a non-combustible construction material (European Fire Class A1). Aluminium alloys will nevertheless melt at around 650°C but without releasing harmful gases

NO RELEASE OF DANGEROUS SUBSTANCES

Several studies have proved that aluminium building products do not present a hazard to occupants or the surrounding environment. Aluminium building products have no negative impact, either on indoor air quality or on soil, surface and groundwater

OPTIMAL SECURITY

Where high security is required, specially designed, strengthened aluminium frames can be used. While the glass for such applications may well be heavy, the overall weight of the structure remains manageable thanks to the light weight of the aluminium frames.

ALLOYS

Aluminium in its pure form is a very soft metal. Thanks to the addition of alloying elements such as copper, manganese, magnesium, zinc, etc. and thanks to suitable production processes, the physical and mechanical properties can be varied in a wide range to satisfy the requirements of a large number of different applications.

The most common aluminium alloy which is used by ETEM is EN AW 6063.

Here are the properties of this alloy:

MATERIAL PROPERTIES

Aluminium alloy	EN AW 6063 F22
Ultimate tensile strength	R _m = 210 N/mm ²
Yield strength	R _{p0,2} = 160 N/mm ²
Modulus of elasticity	E _{al} =70 000 N/mm ² = 7.10 ⁹ kg/m ²
Coefficient of thermal expansion	α=0,023 mm/m .K (up to 1,2 mm/m for difference up to 50°C)

EXTRUSION PROCESS

ETEM profiles are obtained through extrusion process, which consists of pushing a hot cylindrical bullet of aluminium through a shaped die. The extrusion process offers almost infinite range of forms and sections, allowing our designers to integrate numerous functions into one single profile.

FINISHING

POWDER COATING

It is a type of paint that is applied as a dry powder. Coating is applied on ETEM profiles electrostatically and then is cured under heat to allow it to flow and form a "skin".

ETEM is authorized to use the quality sign QUALICOAT for powder coatings on aluminium for architectural applications. A wide range of colors and gloss levels can be achieved. ETEM also offers timber imitations painting, in addition to all RAL colors. The technology EZY provides the following colors: Golden Oak, Acero, Betulla, Mogano, Verde Scuro, Wenge, Noce Fiammato, Noce Chiaro, Ciliegio Rosso, Acacia Scuro, Ciliegio Antico, Noce Reale, Ciliegio Reale.

ANODIZING

It is an electrochemical process whereby to reinforce the natural oxide film on the

ETEM profiles are extruded from the following alloys:
EN AW-1050 [Al 99,5]
EN AW-6060 [Al Mg Si]
EN AW-6063 [Al Mg0,7 Si]
EN AW-6061 [Al Mg1 Si Cu]
EN AW-6005 [Al Si Mg]
EN AW-6082 [Al Si1 Mg Mn]

WIND LOAD

Wind action

The main influence over the facade is wind action, which depends mainly on the height of the curtain wall and location.

As a guideline, the wind pressure values with respect to the structure height are given in the table below:

Building Height	Wind Velocity	Wind Load	Wind Pressure	Wind Suction in a middle zone		Wind Suction in an edge zone
h	v	q = $\frac{V^2}{16}$	W _{p*} = 1,25 x c _p x q c _p = 0,8	h/b ≤ 0,25 W _s = c _p x q c _p = 0,5		h/b ≥ 0,5 W _s = c _p x q c _p = 0,7
m	m/s	kg/m ²	kg/m ²	kg/m ²	kg/m ²	kg/m ²
0 - 8	28,3	50	0,5	50	0,5	25
8 - 20	35,8	80	0,8	80	0,8	40
20 - 100	42,0	110	1,1	110	1,1	55
> 100	45,6	130	1,3	130	1,3	65
				35	0,35	100
				56	0,56	160
				77	0,77	220
				91	0,91	260
						2,6

where:

h - building height, m
b - building width, m
v - wind velocity, m/s
q - wind load, kg/m² and kN/m²
W_{p/s} - wind pressure / suction ,kN/m²
c_p - correction factor

*Note: When calculating wind pressure w_p the load is increased with 25%

MAINTENANCE

Apart from routine cleaning for aesthetic reasons, ETEM aluminium profiles do not require any maintenance which translates into a major cost and ecological advantage over lifetime of the product.

RECYCLING

Aluminium scrap can be repeatedly recycled without any loss of value or properties. In many instances, aluminium is combined with other materials such as steel or plastics, which are most frequently mechanically separated from aluminium before being molten.

UNITS CONVERTER

$$1\text{m} = 100\text{cm} = 1000\text{mm}$$

$$1\text{kg} = 10\text{N} \\ 1\text{kN} = 100\text{kg} = 1000\text{N}$$

$$1\text{kg/m}^2 = 0,01\text{kN/m}^2 \\ 1\text{Pa} = 1\text{N/m}^2 = 0,1\text{kg/m}^2 \\ 1\text{kPa} = 1000\text{Pa} = 1\text{kN/m}^2 = 100\text{kg/m}^2 \\ 1\text{MPa} = 1000\text{kPa} = 1000000\text{ Pa} \\ 1\text{MPa} = 1\text{N/mm}^2 = 0,1\text{kN/cm}^2 = 100000\text{kg/m}^2$$

MULLION SELECTION

*Wind load actions:

The required moment of inertia of a mullion due to the wind action is given by:

a) triangle load

$$\text{If } \frac{H}{c} \leq 1, I_{yc} \geq \frac{w \cdot (H/2) \cdot H^4 \cdot 10^8}{120 \cdot E_{al} \cdot f_{max}}, \text{cm}^4$$

or

b) trapezoid load

$$\text{If } \frac{H}{c} > 1, I_{yc} \geq \frac{w \cdot (C/2) \cdot H^4}{1920 \cdot E_{al} \cdot f_{max}} \cdot 10^8 \left[25 - 40 \cdot \frac{(C/2)^2}{H^2} + 16 \cdot \frac{(C/2)^4}{H^4} \right], \text{cm}^4$$

Use the same method to calculate I_{yd}

Total of required moment of inertia:

$$I_y = I_{yc} + I_{yd}, \text{cm}^4$$

Where:

I_y - Moment of inertia of a transom, cm^4

w - Wind pressure, kg/m^2

E_{al} - Modulus of Elasticity of aluminium, kg/m^2

f_{max} - Maximum transom deflection, m

H - Length of a mullion, m

a, b - Distance between mullions, m

Maximum transom deflection f_{max} by wind load:


$$f = \frac{H}{200}, \text{m} \quad \text{or } 0,015 \text{ m} - \text{whichever is less (EN 14351-1)}$$

Use ETEM Catalogue to choose the appropriate mullion with I_y exceeding or equal to the required I_y .

Use ETEM Catalogue to choose the appropriate profile which characteristics exceed or are equal to both calculated values I_x and I_y .

I_x

Example:



Initial data:

$$H = 2,2 \text{ m}$$

$$c = 2,4 \text{ m}$$

$$d = 0,8 \text{ m}$$

$$w = 60 \text{ kg/m}^2$$

$$E_{al} = 7.10^9 \text{ kg/m}^2$$

$$f = \frac{H}{200} = \frac{2,2}{200} = 0,011 \text{ m} \quad \text{or } 0,015 \text{ m (EN 14351-1)}$$

$\Rightarrow f_{max} = 0,011 \text{ m}$ in the following formulas:

$$\frac{H}{c} = \frac{2,2}{2,4} = 0,91 < 1$$

$$I_{yc} \geq \frac{w \cdot (H/2) \cdot H^4 \cdot 10^8}{120 \cdot E_{al} \cdot f_{max}}, \text{cm}^4$$

$$I_{yc} \geq \frac{60 \cdot (2,2/2) \cdot 2,2^4 \cdot 10^8}{120 \cdot 7 \cdot 10^9 \cdot 0,011}, \text{cm}^4 \Rightarrow I_{yc} \geq 16,73 \text{ cm}^4$$

$$\frac{H}{d} = \frac{2,2}{0,8} = 2,75 > 1$$

$$I_{yd} \geq \frac{w \cdot (d/2) \cdot H^4}{1920 \cdot E_{al} \cdot f_{max}} \cdot 10^8 \left[25 - 40 \cdot \frac{(d/2)^2}{H^2} + 16 \cdot \frac{(d/2)^4}{H^4} \right], \text{cm}^4$$

$$I_{yd} \geq \frac{60 \cdot (0,8/2) \cdot 2,2^4}{1920 \cdot 7 \cdot 10^9 \cdot 0,011} \cdot 10^8 \left[25 - 40 \cdot \frac{(0,8/2)^2}{2,2^2} + 16 \cdot \frac{(0,8/2)^4}{2,2^4} \right], \text{cm}^4$$

$$I_{yd} \geq 9,01 \text{ cm}^4$$

$$I_y = I_{yc} + I_{yd}, \text{cm}^4 \Rightarrow I_y = 16,73 + 9,01 = 25,74 \text{ cm}^4$$

Use ETEM Catalogue to choose the appropriate mullion with $I_y \geq 25,74 \text{ cm}^4$

We choose mullion E75300S with $I_x = 13,91 \text{ cm}^4$ and $I_y = 41,75 \text{ cm}^4$

TRANSOM SELECTION

*Dead load actions:

*Glass pane self weight:

Weight of the glass pane G is calculated as follows:

The required moment of inertia of a transom due to the weight of the glazing is given by:

$$I_{x1} \geq \frac{G \cdot a \cdot 10^8}{48 \cdot E_{al} \cdot f_{max}} \cdot (3 \cdot L^2 - 4 \cdot a^2), \text{cm}^4$$

Where:

G - Weight of glass pane, kg

t - Glass pane thickness, mm

ρ_{glass} - Density of glass material, $\text{kg}/\text{m}^2/\text{mm}$

I_g - Horizontal dimension of the glass pane, m

h_g - Vertical dimension of the glass pane, m

*Transom self weight:

The required moment of inertia of a transom due to its self weight is given by:

$$I_{x2} \geq \frac{5 \cdot q \cdot L^4 \cdot 10^8}{384 \cdot E_{al} \cdot f_{max}}, \text{cm}^4$$

Total of required moment of inertia:

$$I_x = I_{x1} + I_{x2}, \text{cm}^4$$

Where:

$a=0,15$ - Distance of a glazing supports of the glass pane, m

I_x - Moment of inertia of a transom, cm^4

q - Self weight of a transom per linear meter, kg/m

E_{al} - Modulus of Elasticity of aluminium, kg/m^2

f_{max} - Maximum transom deflection, m

L - Length of a transom, m

Maximum transom deflection f_{max} by dead load:


$$f = \frac{L}{500}, \text{m} \quad \text{or } 0,003 \text{ m} - \text{whichever is less (EN 14351-1)}$$

Use ETEM Catalogue to choose the appropriate transom with I_y exceeding or equal to the required I_y .

Use ETEM Catalogue to choose the appropriate profile which characteristics exceed or are equal to both calculated values I_x and I_y .

Example:

$$G = t \cdot \rho_{glass} \cdot I_g \cdot h_g$$



Initial data:

$$t = 12 \text{ mm}$$

$$I_g = 1,5 \text{ m}$$

$$h_g = 2,0 \text{ m}$$

$$a = 0,15 \text{ m}$$

$$G = t \cdot \rho_{glass} \cdot I_g \cdot h_g = 10 \cdot 2,5 \cdot 1,5 \cdot 2,0 = 75 \text{ kg}$$

$$\Rightarrow f_{max} = \frac{L}{500} = \frac{1,5}{500} = 0,003 \text{ m} \quad \text{or } 0,003 \text{ m (EN 14351-1)}$$

$\Rightarrow f_{max} = 0,003 \text{ m}$ in the following formulas:

$$I_{x1} \geq \frac{G \cdot a \cdot 10^8}{48 \cdot E_{al} \cdot f_{max}} \cdot (3 \cdot L^2 - 4 \cdot a^2), \text{cm}^4$$

$$I_{x1} \geq \frac{75 \cdot 0,15 \cdot 10^8}{48 \cdot 7 \cdot 10^9 \cdot 0,003} \cdot (3 \cdot 1,5^2 - 4 \cdot 0,15^2), \text{cm}^4$$

$$I_{x1} \geq \frac{75 \cdot 0,15 \cdot 10^8}{48 \cdot 7 \cdot 10^9 \cdot 0,003} \cdot (3 \cdot 1,5^2 - 4 \cdot 0,15^2), \text{cm}^4 \Rightarrow I_{x1} \geq 7,43 \text{ cm}^4$$

$$I_{x2} \geq \frac{5 \cdot q \cdot L^4 \cdot 10^8}{384 \cdot E_{al} \cdot f_{max}}, \text{cm}^4 \quad J_{x2} \geq \frac{5 \cdot 2 \cdot 1,5^4 \cdot 10^8}{384 \cdot 7 \cdot 10^9 \cdot 0,003}, \text{cm}^4 \Rightarrow I_{x1} \geq 0,63 \text{ cm}^4$$

$$I_x = I_{x1} + I_{x2}, \text{cm}^4$$

$$I_x = 7,43 + 0,63 = 8,06 \text{ cm}^4$$

Use ETEM Catalogue to choose the appropriate transom with $I_x \geq 8,06 \text{ cm}^4$

We choose transom E75300S with $I_x = 13,91 \text{ cm}^4$ and $I_y = 41,75 \text{ cm}^4$

TRANSOM SELECTION

*Wind load actions:

The required moment of inertia of a transom due to the wind action is given by:

a) triangle load

$$\text{If } \frac{L}{a} \leq 1, I_{ya} \geq \frac{w \cdot (L/2) \cdot L^4 \cdot 10^8}{120 \cdot E_{al} \cdot f_{max}}, \text{cm}^4$$

or

b) trapezoid load

$$\text{If } \frac{L}{a} > 1, I_{ya} \geq \frac{w \cdot (a/2) \cdot L^4}{1920 \cdot E_{al} \cdot f_{max}} \cdot 10^8 \left[25 - 40 \cdot \frac{(a/2)^2}{L^2} + 16 \cdot \frac{(a/2)^4}{L^4} \right], \text{cm}^4$$

Use the same method to calculate I_{yb}

Total of required moment of inertia:

$$I_y = I_{ya} + I_{yb}, \text{cm}^4$$

Where:

I_y - Moment of inertia of a transom, cm^4

w - Wind pressure, kg/m^2

E_{al} - Modulus of Elasticity of aluminium, kg/m^2

f_{max} - Maximum transom deflection, m

L - Length of a transom, m

a,b - Distance between transoms, m


Maximum transom deflection f_{max} by wind load:

$$f = \frac{L}{200}, \text{m} \quad \text{or } 0,015 \text{ m} - \text{whichever is less (EN 14351-1)}$$

Use ETEM Catalogue to choose the appropriate transom with I_x exceeding or equal to the required I_x .

Use ETEM Catalogue to choose the appropriate profile which characteristics exceed or are equal to both calculated values I_x and I_y .

Example:



Initial data:

$$L = 1,5 \text{ m}$$

$$w = 60 \text{ kg/m}^2$$

$$a = 0,7 \text{ m}$$

$$E_{al} = 710 \text{ kg/m}^2$$

$$b = 2,0 \text{ m}$$

$$f = \frac{L}{200} = \frac{1,5}{200} = 0,0075 \text{ m} \quad \text{or } 0,015 \text{ m (EN 14351-1)}$$

$\Rightarrow f_{max} = 0,0075 \text{ m}$ in the following formulas:

$$\frac{L}{a} = \frac{1,5}{0,7} = 2,14 > 1$$

$$I_{ya} \geq \frac{w \cdot (a/2) \cdot L^4}{1920 \cdot E_{al} \cdot f_{max}} \cdot 10^8 \left[25 - 40 \cdot \frac{(a/2)^2}{L^2} + 16 \cdot \frac{(a/2)^4}{L^4} \right], \text{cm}^4$$

$$I_{ya} \geq \frac{60 \cdot (0,7/2) \cdot 1,5^4}{1920 \cdot 7 \cdot 10^9 \cdot 0,0075} \cdot 10^8 \left[25 - 40 \cdot \frac{(0,7/2)^2}{1,5^2} + 16 \cdot \frac{(0,7/2)^4}{1,5^4} \right], \text{cm}^4$$

$$I_{ya} \geq 2,41 \text{ cm}^4$$

$$\frac{L}{b} = \frac{1,5}{2,0} = 0,75 < 1$$

$$I_{yb} \geq \frac{w \cdot (L/2) \cdot L^4 \cdot 10^8}{120 \cdot E_{al} \cdot f_{max}}, \text{cm}^4 \quad \Rightarrow I_{yb} \geq \frac{60 \cdot (1,5/2) \cdot 1,5^4 \cdot 10^8}{120 \cdot 7 \cdot 10^9 \cdot 0,0075}, \text{cm}^4$$

$$\Rightarrow I_{yb} \geq 3,62 \text{ cm}^4$$

$$I_y = I_{ya} + I_{yb}, \text{cm}^4$$

$$\Rightarrow I_y = 2,41 + 3,62 = 6,03 \text{ cm}^4$$

Use ETEM Catalogue to choose the appropriate mullion with

$$I_y \geq 6,03 \text{ cm}^4$$

We choose mullion E75300S with $I_x = 13,91 \text{ cm}^4$
and $I_y = 41,75 \text{ cm}^4$

CALCULATION OF GLASS PANE THICKNESS

*Glazing thickness:

For single glazing the minimum thickness is given by the following equations:

$$\text{a) If } \frac{h_g}{l_g} \leq 3, \quad t = \sqrt{\frac{10 \cdot l_g \cdot h_g \cdot w}{72}}, \text{mm}$$

or

$$\text{b) If } \frac{h_g}{l_g} > 3, \quad t = \frac{l_g \cdot \sqrt{10 \cdot w}}{72}, \text{mm}$$

Where:


t - Minimum theoretical glass thickness, mm

w - Wind pressure, kg/m^2

l_g - The smallest dimension of the glass pane, m

h_g - The largest dimension of the glass pane, m

Example:



Initial data:

$$l_g = 1,5 \text{ m}$$

$$h_g = 2,0 \text{ m}$$

$$w = 60 \text{ kg/m}^2$$




$$\frac{h_g}{l_g} = \frac{2}{1,5} = 1,33 \leq 3$$

$$t = \sqrt{\frac{10 \cdot l_g \cdot h_g \cdot w}{72}} = \sqrt{\frac{10 \cdot 1,5 \cdot 2 \cdot 60}{72}} = \sqrt{\frac{1800}{72}} = 5 \text{mm}$$

For double glazing $t_{req} = 1,5 \cdot 5 = 7,5 \text{ mm}$

We choose double glazing 5/14/5

GLAZING SHIMS




■ main glazing shim
□ positioning shim



Note:

Main glazing shims should be positioned on 150 mm distance from the glazing edge.
Positioning shims do not have exactly defined position.

POSITION OF ANCHORS



$a = 150 \div 200 \text{ mm}$
 $b \leq 800 \text{ mm}$



METHOD FOR CALCULATION OF THERMAL TRANSMITTANCE ACCORDING
to EN ISO 10077-2

$$U_w = \frac{A_g \times U_g + A_f \times U_f + l_g \times \Psi_g}{A_g + A_f} \quad (1)$$

U_w - thermo-transmittance coefficient of the whole structure

U_g - glass thermal transmittance coefficient

U_f - thermo-transmittance coefficient of the aluminium frame (frame and sash)

Ψ_g - spacer linear thermal transmittance

l_g - total length of the spacer


A_g - glass area

A_f - aluminium frame area (frame and sash)

U_w - is calculated by formula (1)

U_g - is given by the glass manufacturer

U_f - is given by the manufacturer of the aluminium profiles



EXAMPLE FOR CALCULATING THERMAL TRANSMITTANCE COEFFICIENT

frame: E75 U_f 1.34 W/(m²K)

spacer: warm edge Ψ_g 0.051 W/(m²K)

glass: triple glazing U_g 1.00 W/(m²K)

window width: 1.00 m


window height: 2.00 m

length of glass edge l_g : 4,89 m

$A_g = 1.24 \text{ m}^2; A_f = 0.76 \text{ m}^2$

$$U_w = \frac{1.24 \times 1 + 0.76 \times 1.34 + 4.89 \times 0.051}{1.24 + 0.76}$$

$$U_w \approx 1.3 \text{ W/(m}^2\text{K)}$$




E75FD

FLAT DOOR
SYSTEM WITH
THERMAL BREAK

GENERAL INFORMATION

CONCEPT / ADVANTAGES / CERTIFICATES




E75FD CONCEPT


E75FD WINDOW IS A SYSTEM CORRESPONDING TO THE MOST STRINGENT REQUIREMENTS FOR THERMAL INSULATION, FUNCTIONALITY AND AESTHETICS.

- Elegant straight design
- 75 mm system width allowing usage of triple glazing
- Wide polyamide bars
- Excellent thermal insulation from 1,1 W/m²K
- Additional insulator in the thermo-break area
- Additional insulator under the glass
- Effective drainage
- Excellent water-tightness and air-permeability
- Co-extruded central gasket
- Possibility for mounting anti-burglar hardware for good security performance
- Extruded corners for crimping machine with glue allowing greater connections

ADVANCED SYSTEM



BASIC SYSTEM




TABLES

TYPLOGIES / LIST OF PROFILES / CHARACTERISTICS

flat door system with thermal break

E75FD



flat door system with thermal break

E75FD

code	profile	length weight moment of inertia	code	profile	length weight moment of inertia
E75110 frame-inward		L=6.01 m 1932 g/m $I_x = 27.25 \text{ cm}^4$ $I_y = 49.95 \text{ cm}^4$	E75120 kick plate		L=6.01 m 1899 g/m $I_x = 32.42 \text{ cm}^4$ $I_y = 55.04 \text{ cm}^4$
E75111 frame-outward		L=6.01 m 1891 g/m $I_x = 26.58 \text{ cm}^4$ $I_y = 49.88 \text{ cm}^4$	E75121 kick plate		L=6.01 m 2304 g/m $I_x = 68.11 \text{ cm}^4$ $I_y = 67.91 \text{ cm}^4$
E75210 sash-inward		L=6.01 m 2063 g/m $I_x = 36.18 \text{ cm}^4$ $I_y = 54.04 \text{ cm}^4$	E75304 T profile		L=6.01 m 2427 g/m $I_x = 68.51 \text{ cm}^4$ $I_y = 66.9 \text{ cm}^4$
E75211 sash-outward		L=6.01 m 2073 g/m $I_x = 36.3 \text{ cm}^4$ $I_y = 52.06 \text{ cm}^4$	E75605 adapter		L=6.01 m 274 g/m
E4275606 alignment profile		120 g/m L=6.01 m	E75112 reverse profile		L=6.01 m 1164 g/m $I_x = 5.14 \text{ cm}^4$ $I_y = 22.84 \text{ cm}^4$
E75103 frame		L=6.01 m 2228 g/m $I_x = 57.75 \text{ cm}^4$ $I_y = 62.95 \text{ cm}^4$	E75601 adapter for facade		L=6.01 m 897 g/m $I_x = 1.52 \text{ cm}^4$ $I_y = 10.95 \text{ cm}^4$

flat door system with thermal break

E75FD

code	profile	length weight moment of inertia	code	profile	length weight moment of inertia
E75602 adapter		L=6.01 m 216 g/m	E75801 adapter		L=6.01 m 85 g/m
E75603 round column		L=6.01 m 2232 g/m $I_x = 56.34 \text{ cm}^4$ $I_y = 55.75 \text{ cm}^4$	E75805 bottom rail		L=6.01 m 210 g/m
E75810 door threshold		L=6.01 m 722 g/m	E75811 door threshold		L=6.01 m 723 g/m
E75800 brush-holder		L=6.01 m 497 g/m	E75802 bottom rail		L=6.01 m 85 g/m


PROFILES

DRAWINGS


flat door system with thermal break

E75FD

E75110
frame-inward
1932 g/m




E75111
frame-outward
1891 g/m



scale : 1:1

flat door system with thermal break



E75FD




flat door system with thermal break

E75FD


E4275606
120 g/m



flat door system with thermal break**E75FD**E75120
1899 g/m

scale : 1:1

P75D-04

flat door system with thermal break**E75FD**E75121
2304 g/m


scale : 1:1

P75D-05


flat door system with thermal break

E75FD


E75605
274 g/m



E75112
1164 g/m



E75601
adapter for facade
897 g/m




scale : 1:1

P75D-06


flat door system with thermal break

E75FD

E75602
216 g/m




E75603
2232 g/m




scale : 1:1

P75D-07

E75810
722 g/m




E75811
723 g/m




E75805
210 g/m




E75800
brush-holder
497 g/m



E75802
85 g/m



E75801
85 g/m



scale : 1:1


P75D-08

SECTIONS

SECTIONS / DETAILS

flat door system with thermal break


E75FD



scale : 1:1

flat door system with thermal break

E75FD





scale : 3/4

flat door system with thermal break

E75FD



inward opening



scale : 1:1


flat door system with thermal break

E75FD




flat door system with thermal break

E75FD




inward opening

scale : 1:1




flat door system with thermal break

E75FD




flat door system with thermal break

E75FD



flat door system with thermal break


E75FD



scale : 3/4

flat door system with thermal break


E75FD



scale : 3/4


flat door system with thermal break

E75FD




flat door system with thermal break

E75FD



flat door system with thermal break


E75FD



scale : 3/4

flat door system with thermal break


E75FD



scale : 3/4

flat door system with thermal break

E75FD




SED technical catalogue

58

ETEM

flat door system with thermal break

E75FD




E75ED technical catalogue

59


flat door system with thermal break

E75FD




flat door system with thermal break

E75FD



flat door system with thermal break

E75FD





Attention:
In combination of profile E75300; E75112 and E75211 always use hinges GI051660.01 / GI205040.01 - 84mm with bolt GI205044.00

scale : 3/4

flat door system with thermal break

E75FD




Attention:
In combination of profile E75300; E75605 and gasket ET130491.00 always use hinges GI205035.01 / GI205042.01

scale : 3/4

flat door system with thermal break


E75FD



D75-19

flat door system with thermal break

E75FD



D75-20

GLAZING OPTIONS

flat door system with thermal break

E75FD

external gaskets	GLAZING OPTIONS				GLAZING BEADS		
	INTERNAL GASKETS						
3 mm 130476	5 - 6 mm 130176	7 - 8 mm 130177					
4 mm 130153	5 mm 130205	6 mm 130206	7 mm 130207	8 mm 130208	10 mm 130210		
					X mm		
130476	55	54	53	52	50	security	E602xx
130153	54	53	52	51	49	E4060807	E60207 old code E1144
130476	52	51	50	49	47	E4060810	9.5
130153	51	50	49	48	46	E4060812	E60212
130476	50	49	48	47	45	E4060815	12
130153	49	48	47	46	44	E4060815	E60215
130476	48	47	46	45	43	E4060817	14.5
130153	47	46	45	44	42	E4060817	E60215
130476	45	44	43	42	40	E4060817	17
130153	44	43	42	41	39	E4060817	E60219 old code E5304
130476	43	42	41	40	38	E4060820	18.5
130153	42	41	40	39	37	E4060820	19.5
130476	42	41	40	39	37	E4060822	22
130153	41	40	39	38	36	E4060822	E60222 old code E115
130476	40	39	38	37	35	E4060825	22
130153	39	38	37	36	34	E4060825	E60225 old code E5307
130476	37	36	35	34	32	E4060827	24.5
130153	36	35	34	33	31	E4060827	E60227
130476	35	34	33	32	30	E4060830	27
130153	34	33	32	31	29	E4060830	E60230
130476	32	31	30	29	27	E4060832	29.5
130153	31	30	29	28	26	E4060832	E60230
130476	30	29	28	27	25	E4060835	32
130153	29	28	27	26	24	E4060835	E60235
130476	27	26	25	24	22	E4060837	34.5
130153	26	25	24	23	21	E4060837	E60237
130476	25	24	23	22	20	E4060840	37
130153	24	23	22	21	19	E4060840	E60237
130476	22	21	20	19	17	E4060842	39.5
130153	21	20	19	18	16	E4060842	E60242 old code E75701
130476	20	19	18	17	15	E4060844	42
130153	19	18	17	16	14	E4060844	E60242 old code E75701
130476	17	16	15	14	12	E4060845	44.5
130153	16	15	14	13	11	E4060845	E60247 old code E75700
130476	15	14	13	12	10	E4060847	47
130153	14	13	12	11	9	E4060847	E60247 old code E75700

Note:
Tolerance in dimension chain $\pm 0.5\text{mm}$

T75D-01

**CUTTING LISTS &
MACHININGS**

outward opening - single sash door






		W=width of frame width of sash height of sash H=height of frame	profile selection	calculation of cutting length for one sash door	
			pieces	cutting formula	cutting angles
E75111 frame-outward	width of frame	1	W	2x45°	
	height of frame-left	1	H	1x45° + 1x90° up down	
	height of frame-right	1	H	1x45° + 1x90° up down	
E75211 sash-outward	width of sash-outward	1	W - 109	2x45°	
	height of sash-outward left	1	H - 61,5	1x45° + 1x90° up down	
	height of sash-outward right	1	H - 61,5	1x45° + 1x90° up down	
option 1					
E75120 door kick-plate	width of door kick-plate	1	width of sash-134,5	2x90°	
option 2					
E75121 door kick-plate	width of door kick-plate	1	width of sash-134,5	2x90°	

not to scale

flat door system with thermal break

E75FD

outward opening - single sash door

profile selection		calculation of cutting length for one sash door		
		pieces	cutting formula	cutting angles
E75111 frame-outward 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75211 sash-outward 	width of sash-outward	2	W - 109	2x45°
	height of sash-outward	2	H - 61.5	2x45°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 bottom rail 	width of bottom rail	1	width of sash-32	2x90°
E75801 	width of addition	1	width of sash-47	2x90°
option 2				
E75800 bottom rail - optional finish 	width of bottom rail	1	width of sash-48	2x90°
E75805 - optional finish 	width of door threshold	1	W - 125	2x90°


not to scale

M75D-2

flat door system with thermal break

E75FD

outward opening - single sash door




not to scale

M75D-3

flat door system with thermal break

E75FD


outward opening - single sash door



flat door system with thermal break


E75FD

outward / inward opening - single sash door



flat door system with thermal break

E75FD



bottom rail profile selection		calculation of cutting length for glass unit	
		E75211 sash-outward	E75210 sash-inward
E75120 door kick-plate	width of glass	width of sash-157	width of sash-157
	height of glass	height of sash-157	height of sash-157
E75121 door kick-plate	width of glass	width of sash-157	width of sash-157
	height of glass	height of sash-179	height of sash-179

not to scale

M75D-6

flat door system with thermal break

E75FD

width of sash		width of sash		height of sash		height of sash		sash profile selection		calculation of cutting length for glass unit	
								E75211 sash-outward	E75210 sash-inward		
dimension of glass unit		width of glass		width of sash-157		width of glass		cutting formula		cutting formula	
height of glass		height of sash-157		height of sash-157		height of glass		width of sash-157		width of sash-157	





not to scale

M75D-7

flat door system with thermal break

E75FD

inward opening - single sash door

profile selection		calculation of cutting length for one sash door		
		pieces	cutting formula	cutting angles
E75110 frame-inward 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75210 sash-inward 	width of sash-inward	1	W - 109	2x45°
	height of sash-inward left	1	H - 61,5	1x45° + 1x90° up down
	height of sash-inward right	1	H - 61,5	1x45° + 1x90° up down
option 1				
E75120 door kick-plate 	width of door kick-plate	1	width of sash-134,5	2x90°
option 2				
E75121 door kick-plate 	width of door kick-plate	1	width of sash-134,5	2x90°





not to scale

M75D-8

flat door system with thermal break

E75FD

inward opening - single sash door




profile selection		calculation of cutting length for one sash door		
		pieces	cutting formula	cutting angles
E75110 frame-inward 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75210 sash-inward 	width of sash-inward	2	W - 109	2x45°
	height of sash-inward	2	H - 61,5	2x45°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 bottom rail 	width of bottom rail	1	width of sash-32	2x90°
E75801 	width of addition	1	width of sash-47	2x90°
option 2				
E75800 bottom rail - optional finish 	width of bottom rail	1	width of sash-48	2x90°
E75805 - optional finish 	width of door threshold	1	W - 125	2x90°

not to scale




M75D-9

flat door system with thermal break**E75FD**

inward opening - single sash door

**flat door system with thermal break****E75FD**






inward opening - single sash door



flat door system with thermal break

E75FD

outward opening - double sash door





profile selection		calculation of cutting length for two sash door		
		pieces	cutting formula	cutting angles
E75111 frame-outward 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75211 sash-outward 	width of sash-outward	2	$\frac{W - 94}{2}$	2x45°
	height of sash-outward	2 + 1	H - 61.5	1x45° + 1x90° up down
E75210 sash-inward 	height of sash-inward	1	H - 61.5	1x45° + 1x90° up down
option 1				
E75120 door kick-plate 	width of door kick-plate	2	width of sash-134,5	2x90°
option 2				
E75121 door kick-plate 	width of door kick-plate	2	width of sash-134,5	2x90°
not to scale				

M75D-12

flat door system with thermal break

E75FD

outward opening - double sash door




profile selection		calculation of cutting length for two sash door		
		pieces	cutting formula	cutting angles
E75111 frame-outward 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75211 sash-outward 	width of sash-outward	4	$\frac{W - 94}{2}$	2x45°
	height of sash-outward	2 + 1	H - 61.5	2x45°
E75210 sash-inward 	height of sash-inward	1	H - 61.5	2x45°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 bottom rail 	width of bottom rail	2	width of sash-32	2x90°
E75801 	width of addition	1	width of sash-47 for active sash	2x90°
	width of addition	1	width of sash-25 for passive sash	2x90°
not to scale				

M75D-13

flat door system with thermal break

E75FD

outward opening - double sash door



profile selection		calculation of cutting length for two sash door		
		pieces	cutting formula	cutting angles
option 2				
E75800 bottom rail 	width of bottom rail	1	width of sash-48 for active sash	2x90°
	width of bottom rail	1	width of sash-42 for passive sash	2x90°
E75805 	width of door threshold	1	W - 125	2x90°




not to scale

M75D-14

flat door system with thermal break



E75FD

outward opening - double sash door




E75111
frame-outward

E75111
frame-outward



H=height of frame





not to scale

M75D-15

flat door system with thermal break



E75FD



M75D-16

flat door system with thermal break



E75FD






flat door system with thermal break

E75FD

outward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles



not to scale



$$\text{width of sash} = \frac{W - 94}{2}$$

M75D-18




flat door system with thermal break

E75FD

outward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles



not to scale



$$\text{width of sash} = \frac{W - 94}{2}$$

M75D-19



flat door system with thermal break

E75FD

outward opening - double sash door




Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles




height of sash = H-61.5

M75D-20





These machinings are for door with brush holder E75800 and E75805 threshold




flat door system with thermal break

E75FD



outward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles



Machinings on the bottom and upper side are different





height of sash = H-61.5

M75D-21



flat door system with thermal break

E75FD




outward opening - double sash door



width of door kick-plate



width of door kick-plate




width of door kick-plate = width of sash-134,5

flat door system with thermal break

E75FD


inward opening - double sash door






calculation of cutting
length for two sash door

profile selection

pieces cutting formula cutting angles



E75110
frame-inward



not to scale

width of frame cutting formula cutting angles

1 W 2x45°

1 H 1x45° + 1x90°
up down

1 H 1x45° + 1x90°
up down

2 $\frac{W - 94}{2}$ 2x45°

2 + 1 H - 61.5 1x45° + 1x90°
up down

1 H - 61.5 1x45° + 1x90°
up down


2 width of sash-134,5 2x90°

2 width of sash-134,5 2x90°

flat door system with thermal break

E75FD

inward opening - double sash door




profile selection

calculation of cutting
length for two sash door

	pieces	cutting formula	cutting angles
--	--------	-----------------	----------------

E75110
frame-inward



width of
frame

1	W	2x45°
---	---	-------


height of
frame-left

1	H	1x45° + 1x90° up down
---	---	--------------------------

height of
frame-right

1	H	1x45° + 1x90° up down
---	---	--------------------------

E75210
sash-inward




width of
sash-inward

4	$\frac{W - 94}{2}$	2x45°
---	--------------------	-------

height of
sash-inward

2 + 1	H - 61.5	2x45°
-------------	----------	-------

E75211
sash-outward




height of
sash-outward

1	H - 61.5	2x45°
---	----------	-------

option 1

E75810 or E75811



width of
door threshold

1	W - 143	2x90°
---	---------	-------

E75802
bottom rail



width of
bottom rail

2	width of sash-32	2x90°
---	------------------	-------

E75801



width of
addition

1	width of sash-47 for active sash	2x90°
---	-------------------------------------	-------

width of
addition

1	width of sash-25 for passive sash	2x90°
---	--------------------------------------	-------




not to scale

M75D-24

flat door system with thermal break



E75FD

inward opening - double sash door



calculation of cutting
length for two sash door

	pieces	cutting formula	cutting angles
--	--------	-----------------	----------------




profile selection

calculation of cutting
length for two sash door

	pieces	cutting formula	cutting angles
--	--------	-----------------	----------------

option 2

E75800
bottom rail



width of
bottom rail

1	width of sash-48 for active sash	2x90°
---	-------------------------------------	-------


E75805 - optional finish



width of
bottom rail

1	width of sash-42 for passive sash	2x90°
---	--------------------------------------	-------

E75805 - optional finish



width of
door threshold

1	W - 125	2x90°
---	---------	-------


not to scale

M75D-25

flat door system with thermal break

E75FD


inward opening - double sash door



flat door system with thermal break

E75FD



inward opening - double sash door





flat door system with thermal break

E75FD

inward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles



height of sash = H-61.5



not to scale

M75D-28



flat door system with thermal break

E75FD


inward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles



not to scale



width of sash = $\frac{W - 94}{2}$





M75D-29



flat door system with thermal break

E75FD

inward opening - double sash door



Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles





not to scale

M75D-30



flat door system with thermal break

E75FD

inward opening - double sash door




Sequence of assembly between sash-inward and sash-outward and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00 for sash
E75210 sash-inward + E75211 sash-outward
III - crimp profiles




not to scale

M75D-31

height of sash = H-61.5





These machinings are for door with brush holder E75800 and E75805 threshold



flat door system with thermal break

E75FD

inward opening - double sash door





Sequence of assembly between sash-inward and sash-outward and specific joint corners usage

ET054671.00 + ET054676.00
for sash

E75210 sash-inward + E75211
sash-outward

III - crimp profiles








height of sash = H-61.5

M75D-32


flat door system with thermal break

E75FD


inward opening - double sash door



not to scale width of door kick-plate= width of sash-134,5



E75120 or E75121
door kick-plate





M75D-33




flat door system with thermal break

E75FD

outward opening double sash door






inward opening double sash door







M75D-34

flat door system with thermal break

E75FD




not to scale



M75D-35

flat door system with thermal break


E75FD



not to scale

flat door system with thermal break

E75FD







not to scale




flat door system with thermal break

E75FD

outward opening
double sash door







inward opening
double sash door






flat door system with thermal break

E75FD

outward opening
double sash door



inward opening
double sash door



* The dimensions refer to anodized and mill-finished profiles!




For powder coated profiles, the thickness of the coating must be taken into account!
not to scale

M75D-38

flat door system with thermal break

E75FD

outward opening
double sash door



Note:





This central section of double sash door is equal
for outward opening and inward opening.

not to scale

flat door system with thermal break

E75FD

outward opening - double sash door
combination - E75 flat door + E75




not to scale

flat door system with thermal break

E75FD

inward opening - double sash door
combination - E75 flat door + E75




not to scale

M75D-42

flat door system with thermal break

E75FD


inward opening door combination
E75 flat door + E75



not to scale

M75D-43

machining required on E75211 for lock




* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale*
R=3mm

M75D-44

machining required on E75111 & E75211 for lock





* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale*
R=3mm

M75D-45

flat door system with thermal break

E75FD



* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale


*
R=3mm

M75D-46

flat door system with thermal break

E75FD

machining required on E75111 & E75211 for lock GU.238893.00



* The dimensions refer to anodized and mill-finished profiles!


For powder coated profiles, the thickness of the coating must be taken into account!

not to scale

flat door system with thermal break

E75FD

machining required on E75111 & E75211 for lock GU.238893.00






not to scale

flat door system with thermal break

E75FD






machining required on E75111 & E75211 for hinge ETEM Alpro

outward opening



machining required on E75110 & E75210 for hinge ETEM Alpro

inward opening




* The dimensions refer to anodized and mill-finished profiles!


For powder coated profiles, the thickness of the coating must be taken into account!

not to scale


sequence of assembly and adjustment for hinge ETEM Alpro

outward
opening




machining required on frame E75111 and sash E75211 for hidden hinge Simonswerk TECTUS




machining required on frame E75110 and sash E75210 for hidden hinge Simonswerk TECTUS




TYPE 1: Mounting door sealing system for E75FP double-sash with four side E75211 with brush holder



Caps in the package for door sealing system




not to scale



flat door system with thermal break


E75FD



M75D-54


flat door system with thermal break

E75FD




M75D-55


TYPE 2: Mounting door sealing system for E75 double-sash flat door with kick plate



M75D-56



Note:
Install the cap on the vertical profile of the active wing on the handle side






M75D-57

flat door system with thermal break

E75FD

Machining for door sealing system for E75 double-sash flat door with kick plate





M75D-58

not to scale


flat door system with thermal break

E75FD


Machining for door sealing system for E75 double-sash flat door with kick plate



Note:
Cutting the other wall of the aluminium profile is
not obligatory.




not to scale




M75D-59

TYPE 3: Mounting door sealing system for E75 single-sash flat door with kick plate




not to scale



M75D-60



Sealing system for active sash.
Install cap A₁




Note:
Before installing the cap, remove the part
in which the door sealing system is
positioned



not to scale


M75D-61

TYPE 4: Mounting door sealing system for E75FP single-sash four side E45211 with brush holder



M75D-62

machining required on E75111/E75111 & E75211/E75210 for box locking parts on hinge side
GU235812.00



not to scale

M75D-63


ACCESSORIES

flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 130476.00	60	○

EPDM gasket for glass
elongated



ET 130153.00	150	○
---------------------	-----	---

glazing EPDM gasket 4 mm



ET 130205.00	125	○
---------------------	-----	---

glazing EPDM gasket
press-in 5 mm



ET 990620.00	125	○
---------------------	-----	---

glazing EPDM gasket
press-in 6 mm



flat door system with thermal break**E75FD**

code/description	package/pcs	colour
ET 130207.00	75	○

glazing EPDM gasket
press-in 7 mm



ET 130208.00	40	○
---------------------	----	---

glazing EPDM gasket
press-in 8 mm



ET 130210.00	40	○
---------------------	----	---

glazing EPDM gasket
press-in 10 mm



ET 130176.00	80	○
---------------------	----	---

glazing EPDM gasket
press-in 5-6 mm



A75D-2

flat door system with thermal break**E75FD**

code/description	package/pcs	colour
ET 130177.00	60	○

glazing EPDM gasket
press-in 7-8 mm




ET 130157.00	200	○
---------------------	-----	---

EPDM gasket




ET 080751.00	2	○
---------------------	---	---

additional insulator for E75



ET 130433.00	70	○
---------------------	----	---

gasket for variable angle
E75



flat door system with thermal break

E75FD

code/description	package/pcs	colour
ET 130468.00	100	○

outside silicone gasket




ET 130748.00	100	○
--------------	-----	---

EPDM gasket



ET 130491.00	40	○
--------------	----	---


EPDM gasket



ET 995563.00	1	○
--------------	---	---

SET 1.1KSTP

set pl. plugs for
single-sash flat door with
thermal threshold



A75D-4


flat door system with thermal break

E75FD

code/description	package/pcs	colour
ET 995564.00	1	○

SET 2.1KCCH


set pl. plugs for
single-sash flat door with
brush holder



ET 995565.00	1	○
--------------	---	---

SET 3.1KSP


set pl. plugs for
single-sash flat door with
kick-plate



ET 995566.00	1	○
--------------	---	---

SET 4.2KSTP


set pl. plugs for
double-sash flat door with
thermal threshold



ET 995567.00	1	○
--------------	---	---

SET 5.2KSCH

set pl. plugs for
double-sash flat door with
brush holder




flat door system with thermal break

E75FD

code/description	package/pcs	colour
ET 995568.00	1	○


SET 6.2KSP

set pl. plugs for
double-sash flat door with
kick-plate




ET 991306.00	200	○
--------------	-----	---

equalizing shim 6 mm




ET 074306.00	100	○
--------------	-----	---

plastic drainage cap 30x6mm



ET 074307.00	100	○
--------------	-----	---

flap for drainage cap




A75D-6

flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 074629.00	200	nickel

plastic plug for drip profile
E2357





ET 055516.00	1	-
--------------	---	---

Steel anchor for E75





ET 054674.00	200	MF
--------------	-----	----

extruded aluminium corner
bracket 6.4 mm for
E75111



ET 054675.00	50	MF
--------------	----	----

extruded aluminium corner
bracket 30.4 mm for
E75111/E75210



attention
always use epoxy resin
for long lasting joining

ET 054675.00	50	MF
--------------	----	----



attention
always use epoxy resin
for long lasting joining

flat door system with thermal break

E75FD



code/description	package/pcs	colour
ET 054676.00	200	MF

extruded aluminium corner
bracket 3.9 mm for
E75210





ET 054670.00	150	MF
--------------	-----	----

extruded aluminium corner
bracket 6.4 mm for
E75110





ET 054671.00	100	MF
--------------	-----	----

extruded aluminium corner
bracket 21.9 mm for
E75110/E75211



ET 054672.00	100	MF
--------------	-----	----

extruded aluminium corner
bracket 8.2 mm for
E75110/E75211



attention
always use epoxy resin
for long lasting joining





flat door system with thermal break

E75FD

code/description	package/pcs	colour
ET 054673.00	100	MF

extruded aluminium corner
bracket 12.4 mm for
E75211





attention
always use epoxy resin
for long lasting joining


ET 054553.00	100	MF
--------------	-----	----

ET 054885.00	-	MF
--------------	---	----

extruded aluminium corner
bracket



extruded aluminium shimming
corner





attention
always use epoxy resin
for long lasting joining



ET 054311.00	100	MF
--------------	-----	----

ET 054886.00	-	MF
--------------	---	----

extruded aluminium corner
bracket





extruded aluminium shimming
corner



attention
always use epoxy resin
for long lasting joining

ET 054722.00	75	MF
--------------	----	----

extruded aluminium corner
bracket 30.7 mm for
E75112




attention
always use epoxy resin
for long lasting joining

flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 055511.00	100	MF

alignment square - inox
for E75112



ET 058001.00	250	MF
--------------	-----	----

alignment square with
locking function




ET 991407.00	10	MF
--------------	----	----

T - bracket external side
for E75300/E75340



ET 070206.00	10	MF
--------------	----	----

T - bracket internal side for
E75300/E75340



flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 070308.00	10	MF

T - bracket external side




ET 070212.00	10	MF
--------------	----	----

T - bracket internal side




ET 070310.00	10	MF
--------------	----	----

T - bracket external side



ET 070214.00	10	MF
--------------	----	----

T - bracket internal side




flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 070309.00	10	MF

T - bracket external side




ET 070213.00	10	MF
---------------------	----	----

T - bracket internal side




GI205035.01	10	●
GI205035.04	10	●
GI205035.02	10	○

double hinge for flat door
Domina



ET GI205042.01	5	●
ET GI205042.02	5	●
ET GI205042.11	5	●

triple hinge for flat door
Domina




A75D-12

flat door system with thermal break

E75FD


code/description	package/pcs	colour
GI205039.00	24	MF

bolt adjustable spacer 48mm
for hinge Domina




GI255616.00	24	MF
--------------------	----	----

conter plate kit for hinge
Domina




GI051660.01	1	●
GI051660.02	1	●
GI051660.11	1	EV1

double hinge for flat door
Domina - 84mm



GI205040.01	1	●
GI205040.02	1	●
GI205040.11	-	EV1

triple hinge for flat door
Domina - 84mm




flat door system with thermal break

E75FD

code/description	package/pcs	colour
GI205044.00	24	MF

expansion plugs Domina




GI 205040.00	20	MF
---------------------	----	----

direct screw 12x75 for hinge
Domina




ET 205114.01	2	●
ET 205114.02	2	○
ET 205114.11	2	EV1

hinge ETEM Alpro



ET 205101.06	1	●
ET 205101.02	1	○

hidden hinge Simonswerk
TECTUS




A75D-14

flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 205102.00	1	MF

fixing set for TECTUS



GU235824.00	1	-
--------------------	---	---

cylinder 35/65mm




GU 238893.00	1	nickel
---------------------	---	--------

Security lock GU 35/92/240



GU235841.00	1	-
--------------------	---	---

Striker Up/Bottom




flat door system with thermal break

E75FD


code/description	package/pcs	colour
GU235804.00	1	-

Middle strike plate
Left




code/description	package/pcs	colour
GU235805.00	1	-

Middle strike plate
Right




code/description	package/pcs	colour
GI02790.01	10	●
GI02790.06	10	●
GI02790.02	10	○

Double handle for door prima



code/description	package/pcs	colour
GI206672.01	10	●
GI206670.02	10	○
GI206671.06	10	●

cover plate for cylinder




A75D-16

flat door system with thermal break

E75FD


code/description	package/pcs	colour
GI039910.01	10	●
GI039910.02	10	○
GI039910.06	10	●
GI039910.12	10	EV1 brushed

NP ultra door handle squared




code/description	package/pcs	colour
GI039920.01	10	●
GI039920.02	10	○
GI039920.06	10	●
GI039920.12	10	EV1 brushed

NP ultra door handle rounded




code/description	package/pcs	colour
GI050440.01	10	●
GI050440.02	10	○
GI050440.06	10	●
GI050440.12	10	EV1 brushed

NP ultra door handle ETEM



code/description	package/pcs	colour
GU24315.01	10	●
GU24315.02	10	○
GU24315.06	10	●
GU24315.12	10	EV1 brushed

cylinder cover squared




flat door system with thermal break

E75FD


code/description	package/pcs	colour
ET 994573.00	10	●

bolt for secondary sash
GISSSE




GU235812.00	1	-
-------------	---	---

box locking parts on hinge
side U24x6




GI206699.00	100	nickel
-------------	-----	--------

striker for threshold giesse



GI206682.00	10	-
-------------	----	---

bottom striker for side hung
bolt



A75D-18


ETEM

flat door system with thermal break

E75FD


code/description	package/pcs	colour
GI206681.00	10	-

upper striker for side hung
bolt






ET 074075.00	1	-
--------------	---	---

striker plate






ET 080525.00	2m	standard
--------------	----	----------

additional insulator for
E75110
E75111



ET 080526.00	2m	standard
--------------	----	----------


additional insulator for
E75210
E75211



flat door system with thermal break**E75FD**

code/description	package/pcs	colour
FA 134251.00	1	-

Automatic door sealing
systems - 1000 mm

**E75FPD****FLAT PANEL DOOR
SYSTEM WITH
THERMAL BREAK**

GENERAL INFORMATION

CONCEPT / ADVANTAGES / CERTIFICATES



E75FPD SYSTEM CONCEPT

E75FPD FLAT DOOR SYSTEM IS A PREMIUM SOLUTION ENSURING EXCELLENT THERMAL INSULATION, COMFORT AND EXQUISITE APPEARANCE.


- Elegant straight design
- 75 mm system width allowing usage of triple glazing
- Flushing between opening parts and fixed positions
- Double sash flat doors
- Additional insulator in the thermo-break area
- Additional insulator under the glass
- Anti bi-metal polyamide
- Possibility for automatization
- Opportunity for manufacturing sashes with big dimensions
- Possibility for mounting anti-burglar hardware for good security performance
- Extruded corners for crimping machine with glue allowing greater connections

TABLES

TYPLOGIES / LIST OF PROFILES / CHARACTERISTICS

flat panel door system with thermal break

E75FPD



not to scale

flat door system with thermal break

E75FPD

code	profile	weight length moment of inertia	code	profile	weight length moment of inertia
E75110 frame-inward		L=6.01 m 1932 g/m $I_x = 27.25 \text{ cm}^4$ $I_y = 49.95 \text{ cm}^4$	E75601 adapter for facade		L=6.01 m 897 g/m $I_x = 1.52 \text{ cm}^4$ $I_y = 10.95 \text{ cm}^4$
E75111 frame-outward		L=6.01 m 1891 g/m $I_x = 26.58 \text{ cm}^4$ $I_y = 49.88 \text{ cm}^4$	E75605 adapter		L=6.01 m 274 g/m
E75271 sash-inward		L=6.01 m 1771 g/m $I_x = 22.44 \text{ cm}^4$ $I_y = 36.39 \text{ cm}^4$	E75112 reverse profile		L=6.01 m 1164 g/m $I_x = 5.14 \text{ cm}^4$ $I_y = 22.84 \text{ cm}^4$
E75270 sash-outward		L=6.01 m 1768 g/m $I_x = 22.45 \text{ cm}^4$ $I_y = 35.63 \text{ cm}^4$	E75602 adapter		L=6.01 m 216 g/m
E75372 T-profile		L=6.01 m 1216 g/m $I_x = 8.03 \text{ cm}^4$ $I_y = 22.3 \text{ cm}^4$	E75603 round column		L=6.01 m 2232 g/m $I_x = 56.34 \text{ cm}^4$ $I_y = 55.75 \text{ cm}^4$
E75655 connecting profile		L=6.01 m 941 g/m $I_x = 0.98 \text{ cm}^4$ $I_y = 19.48 \text{ cm}^4$	E75810 door threshold		L=6.01 m 722 g/m

flat door system with thermal break

E75FPD

code	profile	weight length moment of inertia	code	profile	weight length moment of inertia
E75811 door threshold		L=6.01 m 723 g/m			
E75800 brush-holder		L=6.01 m 497 g/m			
E75802 bottom rail		L=6.01 m 85 g/m			
E75805 bottom rail		L=6.01 m 210 g/m			


PROFILES

DRAWINGS


flat panel door system with thermal break

E75FPD



E75110
1932 g/m








E75111
1891 g/m



scale : 1:1

flat panel door system with thermal break**E75FPD**E75271
1771 g/mE75270
1768 g/m

scale : 1:1


flat panel door system with thermal break**E75FPD**E75372
1216 g/mE75655
941 g/mE75601
897 g/mE75605
274 g/mE75112
1164 g/m

scale : 1:1


flat panel door system with thermal break

E75FPD

E75602
216 g/m



E75603
2232 g/m




scale : 1:1

P E75 FPD-04


flat panel door system with thermal break

E75FPD


E75810
722 g/m




E75811
723 g/m




E75805
210 g/m



E75800
497 g/m



E75802
85 g/m



scale : 1:1

P E75 FPD-05



SECTIONS

SECTIONS / DETAILS

flat panel door system with thermal break

E75FPD

outward opening




scale : 1:1


flat panel door system with thermal break

E75FPD

outward opening



1
out



Note:

For inward opening detail is the same!


scale : 1:1

D E75 FPD-2

flat panel door system with thermal break

E75FPD

outward opening




scale : 1:1

D E75 FPD-3


flat panel door system with thermal break

E75FPD




flat panel door system with thermal break

E75FPD




flat panel door system with thermal break

E75FPD




flat panel door system with thermal break

E75FPD




flat panel door system with thermal break

E75FPD




flat panel door system with thermal break

E75FPD



flat panel door system with thermal break


E75FPD



scale : 3/4

flat panel door system with thermal break

E75FPD




scale : 3/4

E75FPD technical catalogue

191

flat panel door system with thermal break


E75FPD



scale : 3/4

flat panel door system with thermal break


E75FPD



scale : 3/4

flat panel door system with thermal break


E75FPD



scale : 3/4

flat panel door system with thermal break

E75FPD



scale : 3/4


CUTTING LISTS & MACHINING






outward opening - single sash door

		calculation of cutting length for one sash door		
profile selection		pieces	cutting formula	cutting angles
E75111 frame-outward	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75270 sash-outward	width of sash-outward	2	W - 109	2x45°
	height of sash-outward	2	H - 61.5	2x45°
E75372 T-profile	width of T-profile	2	W - 244	2x90°
option 1				
E75810 or E75811	width of door threshold	1	W - 143	2x90°
E75802 bottom rail	width of bottom rail	1	width of sash-32	2x90°
option 2				
E75800 bottom rail optional finish	width of bottom rail	1	width of sash-48	2x90°

not to scale

inward opening - single sash door




profile selection				
calculation of cutting length for one sash door				
	pieces	cutting formula	cutting angles	
E75110 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up up
	height of frame-right	1	H	1x45° + 1x90° down down
E75271 	width of sash-outward	2	W - 109	2x45°
	height of sash-outward	2	H - 61.5	2x45°
E75372 	width of T-profile	2	W - 244	2x90°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 	width of bottom rail	1	width of sash-32	2x90°
option 2				
E75800 optional finish 	width of bottom rail	1	width of sash-48	2x90°
E75805 optional finish 	width of door threshold	1	W - 125	2x90°

not to scale

M E75 FPD-3


Calculation of cutting length for panel's sheet for one leaf doors with four side sash profile

Option with four side sash profile - E75270/E75271



flat panel door system with thermal break**E75FPD**


Dimension shown below is valid for locking hardware GU.238893.00



not to scale

flat panel door system with thermal break**E75FPD**

Dimension shown below is valid for locking hardware GU.238893.00








not to scale

flat panel door system with thermal break

E75FPD

outward opening - double sash door

profile selection		calculation of cutting length for two sash door		
		pieces	cutting formula	cutting angles
E75111 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75270 	width of sash-outward	4	$\frac{W - 94}{2}$	2x45°
	height of sash-outward	2 + 1	H - 61.5	2x45°
E75271 	height of sash-inward	1	H - 61.5	2x45°
E75372 	width of T-profile	4	$\frac{W - 364}{2}$	2x90°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 	width of bottom rail	2	width of sash-32	2x90°
option 2				
E75800 	width of bottom rail	1	width of sash-48 for active sash	2x90°
	width of bottom rail	1	width of sash-42 for passive sash	2x90°
E75805 	width of door threshold	1	W - 125	2x90°






not to scale

M E75 FPD-7

flat panel door system with thermal break

E75FPD

inward opening - double sash door

profile selection		calculation of cutting length for two sash door		
		pieces	cutting formula	cutting angles
E75110 	width of frame	1	W	2x45°
	height of frame-left	1	H	1x45° + 1x90° up down
	height of frame-right	1	H	1x45° + 1x90° up down
E75271 	width of sash-outward	4	$\frac{W - 94}{2}$	2x45°
	height of sash-outward	2 + 1	H - 61.5	2x45°
E75270 	height of sash-inward	1	H - 61.5	2x45°
E75372 	width of T-profile	4	$\frac{W - 364}{2}$	2x90°
option 1				
E75810 or E75811 	width of door threshold	1	W - 143	2x90°
E75802 	width of bottom rail	2	width of sash-32	2x90°
option 2				
E75800 	width of bottom rail	1	width of sash-48 for active sash	2x90°
	width of bottom rail	1	width of sash-42 for passive sash	2x90°
E75805 	width of door threshold	1	W - 125	2x90°



not to scale

M E75 FPD-9

flat panel door system with thermal break


E75FPD

outward opening
double sash door






Sequence of assembly between
sash-inward and sash-outward
and specific joint corners usage
I - glue plugs to the profile
II - insert corner brackets in combination
ET054671.00 + ET054676.00
for sash
E75271 sash-inward + E75270
sash-outward
III - crimp profiles

Front view



Back view




not to scale

M E75 FPD-11





flat panel door system with thermal break

E75FPD

outward opening
double sash door



inward opening
double sash door




not to scale

M E75 FPD-13

flat panel door system with thermal break

E75FPD

machining required on E75270 for lock



M E75 FPD-14


* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale

flat panel door system with thermal break

E75FPD

machining required on E75111 & E75270 for lock





M E75 FPD-15

* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale

flat panel door system with thermal break

E75FPD



* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!
not to scale


M E75 FPD-16

*
R=3mm

flat panel door system with thermal break

E75FPD

machining required on E75111 & E75270 for lock




* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!

not to scale

flat panel door system with thermal break

E75FPD



* The dimensions refer to anodized and mill-finished profiles!

For powder coated profiles, the thickness of the coating must be taken into account!




not to scale

flat panel door system with thermal break

E75FPD




machining required on E75111 & E75270 for hinge ETEM Alpro

outward opening



machining required on E75110 & E75271 for hinge ETEM Alpro


inward opening



flat panel door system with thermal break

E75FPD

machining required on E75111 & E75270 for box locking parts on hinge side GU235812.00




not to scale

flat panel door system with thermal break

E75FPD


sequence of assembly and adjustment for hinge ETEM Alpro



flat panel door system with thermal break

E75FPD

machining required on frame E75111 and sash E75270 for hidden hinge Simonswerk TECTUS




Note:
Adding additional hinge,
depend of weight of sash!!

not to scale

flat panel door system with thermal break

E75FPD

machining required on frame E75110 and sash E75210 for hidden hinge Simonswerk TECTUS




Note:
Adding additional hinge,
depend of weight of sash

not to scale

flat panel door system with thermal break

E75FPD

Additional treatment of profiles for ventilation




M E75 FPD-23

flat panel door system with thermal break


E75FPD

Additional treatment of profiles for ventilation and drainage




M E75 FPD-24

MOUNTING SEQUENCE OF FLAT MATERIALS TO THE SASH OF
FLAT PANEL DOOR




A. PREPARING THE PROFILE BEFORE PLACING THE FLAT MATERIAL

- 1 Spray the metal frame with 3M VHB Surface Cleaner. Wipe (in one direction) the 3M VHB Surface Cleaner off with a clean lint free towel.
- 2 Abrade with Scotch Brite 7447A-VFN.
- 3 Repeat step 1 and wait for the surface to dry.
- 4 Apply a primer ET994353.00 for better contact between the surface and the tape ET133504.00





- 5 Apply tape ET133504.00 by hand or use VHB tape applicator Roll down tape ET133504.00 with roller. Check presence of air bubbles under the tape - and remove them



M E75 FPD-25

- 6 Remove partly the tape ET133504.00 protector layer. Full removal of the protector layer is performed after positioning of the flat material




N.B. The thickness of the flat material used shall not exceed 2-3 mm.

B. PREPARATION OF THE FLAT MATERIAL BEFORE INSTALLATION


- 7 Repeat steps 1,2,3,4 on the flat material surface in the bonding area.
- 8 It is recommended to place spacers for more precise positioning of the flat material to bonding.
- 9 Before placing the flat material, apply polyurethane glue that will be in contact with the insulation layer
- 10 Put the teflon tapes under the flat material in order to position properly the flat material before gluing. It is recommended vacuum lifter to be used.
- 11 Once the flat material has been laid, remove the protector of the tape ET133504.00, the spacer, and apply pressure (min 100 kPa) to the areas with the tape ET133504.00 for good adhesion.

Repeat the steps for mounting the flat material on all sides.




M E75 FPD-26



Mounting door sealing system for E75FP double-sash with four side E75270 with brush holder




(A) Sealing system for active sash.
Install cap A₁




(B) Sealing system for passive sash.
Install cap B₁







Caps in the package for door sealing system



M E75 FPD-27




Note:
Install the caps on both wings but only on the sash - frame side. In the middle the caps are different.





Note:
Before installing the cap, remove the part in which the door sealing system is positioned

M E75 FPD-28



Note:
Install the cap on the vertical profile of the passive sash from the handle side



M E75 FPD-29

ACCESSORIES

flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 130502.00	200	○

EPDM gasket




ET 130053.00	-	○
---------------------	---	---

EPDM gasket



ET 130468.00	100	○
---------------------	-----	---

outside silicone gasket



ET 130748.00	100	○
---------------------	-----	---

EPDM gasket




flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 130491.00	40	●

EPDM gasket





ET 130702.00	12	●
--------------	----	---

silicone gasket for E75 FPD





ET 054674.00	200	MF
--------------	-----	----

extruded aluminium corner
bracket 6.4 mm for
E7511



ET 054675.00	50	MF
--------------	----	----

extruded aluminium corner
bracket 30.4 mm for
E7511/E75210



attention
always use epoxy resin
for long lasting joining



A E75 FPD-2

flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 054670.00	150	MF




extruded aluminium corner
bracket 6.4 mm for
E75110



attention
always use epoxy resin
for long lasting joining

ET 054671.00	100	MF
--------------	-----	----



extruded aluminium corner
bracket 21.9 mm for
E75110/E75211/E75270



attention
always use epoxy resin
for long lasting joining

ET 054672.00	100	MF
--------------	-----	----



extruded aluminium corner
bracket 8.2 mm for
E75110/E75211



attention
always use epoxy resin
for long lasting joining

ET 054722.00	75	MF
--------------	----	----

extruded aluminium corner
bracket 30.7 mm for
E75112




A E75 FPD-3

flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 054726.00	-	MF


extruded aluminium corner
bracket 26.4 mm for
E75271



attention
always use epoxy resin
for long lasting joining

ET 054725.00	-	MF
--------------	---	----


extruded aluminium corner
bracket 8.4 mm for
E75270



attention
always use epoxy resin
for long lasting joining

ET 054724.00	-	MF
--------------	---	----


extruded aluminium corner
bracket 8.4 mm for
E75270/E75271



attention
always use epoxy resin
for long lasting joining

ET 054676.00	200	MF
--------------	-----	----

extruded aluminium corner
bracket 3.9 mm for
E75210



attention
always use epoxy resin
for long lasting joining


A E75 FPD-4

flat panel door system with thermal break

E75FPD


code/description	package/pcs	colour
ET 055511.00	100	MF

alignment square - inox
for E75112





ET 055516.00	1	-
--------------	---	---

Steel anchor for E75





ET 080525.00	2m	standard
--------------	----	----------

additional insulator for
E75110
E75111



ET 080526.00	2m	standard
--------------	----	----------

additional insulator for
E75210
E75211




flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 975372.22	1m	standard

additional insulator for
E75372



ET 130509.00	40	●
--------------	----	---


gasket for
E75 FPD



ET 995564.00	1	●
--------------	---	---

SET 2.1KCCH


set pl. plugs for
single-sash flat door
with brush holder



ET 995569.00	1	●
--------------	---	---

SET 1

set plugs for
E75 FDP
with thermal threshold



A E75 FPD-6


flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
ET 995579.00	1	●

SET 2


set plugs for double sash
E75 FDP
with brush holder



ET 995589.00	1	●
--------------	---	---


SET 3

set plugs for double sash E75
FDP
with thermal threshold



ET 070117.00	-	MF
--------------	---	----

aluminium corner for FPD +
screws



ET 994353.00	-	-
--------------	---	---


Primer



flat panel door system with thermal break

E75FPD


code/description	package/pcs	colour
ET 133504.00	-	-



Type VHB 19mm


ET 074306.00	100	○
---------------------	-----	---

plastic drainage cap 30x6mm




ET 074307.00	100	○
---------------------	-----	---

flap for drainage cap



GU 238893.00	1	nickel
---------------------	---	--------

Security lock GU 35/92/240



A E75 FPD-8

flat panel door system with thermal break

E75FPD


code/description	package/pcs	colour
GU235841.00	-	-

Striker Up/Bottom




GU235804.00	-	-
--------------------	---	---

Middle strike plate
Left




GU235805.00	-	-
--------------------	---	---

Middle strike plate
Right



GI027920.01	10	○
GI027920.06	10	●
GI027920.02	10	○


Double handle for door Prima



flat panel door system with thermal break


E75FPD

code/description	package/pcs	colour
GI206672.01	10	●
GI206670.02	10	○
GI206671.06	10	■




cover plate for cilinder

GI039910.01	-	●
GI039910.02	-	○
GI039910.06	-	■
GI039910.12	-	EV1 brushed




NP ultra door handle squared

GI039920.01	-	●
GI039920.02	-	○
GI039920.06	-	■
GI039920.12	-	EV1 brushed



NP ultra door handle rounded

GI050440.01	-	●
GI050440.02	-	○
GI050440.06	-	■
GI050440.12	-	EV1 brushed



NP ultra door handle ETEM


A E75 FPD-10

flat panel door system with thermal break

E75FPD


code/description	package/pcs	colour
GU24315.01	-	●
GU24315.02	-	○
GU24315.06	-	■
GU24315.12	-	EV1 brushed

cylinder cover squared



GU235824.00


-



cylinder 35/65mm


ET 205114.01	2	●
ET 205114.02	2	○
ET 205114.11	2	■

hinge ETEM Alpro



ET 205101.06	2	●
ET 205101.02	2	○

hidden hinge Simonswerk
TECTUS




A E75 FPD-11

flat panel door system with thermal break

E75FPD


code/description	package/pcs	colour
ET 205102.00	1	MF

fixing set for TECTUS



GU235812.00

-




box locking parts on hinge
side U24x6

ET 994573.00

10

○




bolt for secondary sash
GIESSE

GI206699.00

100

nickel



striker for threshold giesse



A E75 FPD-12

flat panel door system with thermal break

E75FPD

code/description	package/pcs	colour
GI206682.00	-	-


bottom striker for side hung
bolt



GI206681.00

-

-





upper striker for side hung
bolt

ET 074075.00

-

-



striker plate

CE MARKING

STANDARDS / PERFORMANCE CHARACTERISTICS

CE MARKING

WHAT DOES THE SIGN CE MEAN?

It is an abbreviation of the French "Conformite Europeene"- i.e. European Conformity. By placing the CE marking the manufacturer declares that the product complies with the general safety requirements set out in the Construction Product Regulation 305/2011.

WHAT IS THE PURPOSE OF CE MARKING?

The CE marking represents "the European passport" of the product, its main objectives are:

CE is a declaration by the manufacturer that the product meets the essential requirements of relevant European legislation relating to health, safety and environmental protection;

CE indicates to officials in relevant ministries and departments that the product can be put on the market lawfully in the country;

CE ensures free movement of goods within the EU and the European Free Trade Association (EFTA);

CE permits the withdrawal of products that do not meet the standards by monitoring and custom authorities;

Marking with the CE mark is necessary in cases where the product is distributed within the internal market.

WHAT ARE THE REQUIREMENTS FOR THE CE MARKING?

Doors, windows and gates (except those intended to be used for internal communication only, for fire/smoke compartmentation and on escape routes) are covered by System 3 of assessment and verification of constancy of performance.

According to the Construction Product Regulation 305/2011, this system sets the following duties:


Tasks to be performed by the manufacturer	Tasks to be performed by Notified testing laboratory	Conformity assessment (the basis for CE marking, which is set by the final producer)
factory production control - FPC	Determination of the product type on the basis of type testing, type calculation, tabulated values, etc.	Declaration of performance issued by the manufacturer or his authorized representative based on test results.

LEGAL ACTS

- Construction Products Regulation (305/2011/EU – CPR) – replacing the Construction Products Directive (89/106/EEC – CPD)
- EN 14351-1:2006+A1:2010 – Windows and doors – Product standard, performance characteristics – Part 1: Windows and external pedestrian doorsets without resistance to fire and/or smoke leakage characteristics

MAIN METHODS FOR OBTAINING TEST RESULTS BY THE MANUFACTURER

According to the Construction Product Regulation 305/2011 there are three main options for the manufacturers of windows and doors to obtain test results.



STANDARDS

GENERAL


- EN 12020 (1÷2) – ALUMINIUM AND ALUMINIUM ALLOYS – EXTRUDED PRECISION PROFILES IN ALLOYS EN AW-6060 AND EN AW-6063
- EN 755 (1÷9) – ALUMINIUM AND ALUMINIUM ALLOYS – EXTRUDED ROD/BAR, TUBE AND PROFILES
- EN 573 (1÷3) – ALUMINIUM AND ALUMINIUM ALLOYS – CHEMICAL COMPOSITION AND FORM OF WROUGHT PRODUCTS
- EN 1990 EUROCODE – BASIS OF STRUCTURAL DESIGN
- EN 1991 EUROCODE 1 – ACTIONS ON STRUCTURES
- EN 1998 EUROCODE 8 – DESIGN OF STRUCTURES FOR EARTHQUAKE RESISTANCE
- EN 1999 EUROCODE 9 – DESIGN OF ALUMINIUM STRUCTURES

WINDOWS AND DOORS

1. EN 14351 – WINDOWS AND DOORS – PRODUCT STANDARD, PERFORMANCE CHARACTERISTICS
2. EN 12519 – WINDOWS AND PEDESTRIAN DOORS – TERMINOLOGY
3. EN 12207 – WINDOWS AND DOORS – AIR PERMEABILITY – CLASSIFICATION
4. EN 1026 – WINDOWS AND DOORS – AIR PERMEABILITY – TEST METHOD
5. EN 12208 – WINDOWS AND DOORS – WATERTIGHTNESS – CLASSIFICATION
6. EN 1027 – WINDOWS AND DOORS – WATERTIGHTNESS – TEST METHOD
7. EN 12210 – WINDOWS AND DOORS – RESISTANCE TO WIND LOAD – CLASSIFICATION
8. EN 12211 – WINDOWS AND DOORS – RESISTANCE TO WIND LOAD – TEST METHOD
9. EN 1191 – WINDOWS AND DOORS – RESISTANCE TO REPEATED OPENING AND CLOSING – TEST METHOD
10. EN ISO 10077 (1÷2) – THERMAL PERFORMANCE OF WINDOWS, DOORS AND SHUTTERS – CALCULATION OF THERMAL TRANSMITTANCE
11. EN 12412-2 – THERMAL PERFORMANCE OF WINDOWS, DOORS AND SHUTTERS – DETERMINATION OF THERMAL TRANSMITTANCE BY HOT BOX METHOD – PART 2: FRAMES
12. EN 13115 – WINDOWS – CLASSIFICATION OF MECHANICAL PROPERTIES – RACKING, TORSION AND OPERATING FORCES
13. EN 1627 – WINDOWS, DOORS, SHUTTERS – BURGLAR RESISTANCE – REQUIREMENTS AND CLASSIFICATION
14. EN 1628 – WINDOWS, DOORS, SHUTTERS – BURGLAR RESISTANCE – TEST METHOD FOR THE DETERMINATION OF RESISTANCE UNDER STATIC LOADING
15. EN 1629 – WINDOWS, DOORS, SHUTTERS – BURGLAR RESISTANCE – TEST METHOD FOR THE DETERMINATION OF RESISTANCE UNDER DYNAMIC LOADING
16. EN 1630 – WINDOWS, DOORS, SHUTTERS – BURGLAR RESISTANCE – TEST METHOD FOR THE DETERMINATION OF RESISTANCE TO MANUAL BURGLARY ATTEMPTS
17. EN ISO 717-1 – ACOUSTICS – RATING OF SOUND INSULATION IN BUILDINGS AND OF BUILDING ELEMENTS – PART 1: AIRBORNE SOUND INSULATION
18. EN ISO 10140 – ACOUSTICS – LABORATORY MEASUREMENT OF SOUND INSULATION OF BUILDING ELEMENTS

HATCHES


Hatches for different materials



EPDM



butyl seal




PVC



membrane



gypsum board



silicone seal


backer rod



silicone seal




PVC spacer



Insulation soft




etalbond




Insulation hard




sheet aluminium



concrete wall




glass



plaster



aluminium profile



wood



steel

LIABILITY

The stated data and calculating methods are provided by ETEM as a guideline only. The information given in this catalogue does not substitute all applicable regulations – Eurocodes, harmonized European standards, national or regional building codes.

The specific conditions and technical details of every particular project have to be taken into consideration.

The right choice of all elements as well as any special requirements regarding stability of the structure must always be considered by the structural/façade engineer, responsible for the project.

The solutions presented in these pages are indicative and can not cover all possible project cases. Because of that every single project has to be evaluated by the structural/façade engineer in charge taking into consideration the specific features, such as climate conditions, location, orientation, etc.

ETEM is not liable for any calculations and conclusions made on the basis of the stated information. All calculations and specifications must be estimated, endorsed and guaranteed by architect, engineer, professional or legal entity authorized by law for such activities.

COPYRIGHT

Copyright© 1 edition, 2023 ETEM

The design, structure and content of this catalogue are subject of copyright and the exclusive rights belong to ETEM. Modifying, copying, publishing, selling or licensing any part or the whole content of this catalogue is strongly prohibited without the permission of ETEM.

Any unauthorized use of content may violate copyright or other laws.

DISCLAIMER


ETEM is not responsible for any typographical errors, technical inaccuracies and following changes of the content of this catalogue.

Before starting manufacturing process, it is highly recommended to contact ETEM R&D department in order to provide you with updated information.





DISCOVER MORE:



ETEM
etem.com